

greenworks

2501373

EN

LAWN MOWER

OPERATOR MANUAL



LMF401



Original Instructions/기본 지침서/คำแนะนำเดิม /使用手册原版翻译/使用手册原版翻译

1	Description.....	4	4	Operation.....	5
1.1	Purpose.....	4	4.1	Start the machine.....	5
1.2	Overview.....	4	4.2	Stop the machine.....	5
2	Safety.....	4	4.3	Empty the grass catcher.....	6
3	Installation.....	4	4.4	Operate on slopes.....	6
3.1	Unpack the machine.....	4	4.5	Operation tips.....	6
3.2	Unfold the lower handle.....	4	5	Maintenance.....	6
3.3	Install the upper handle	4	5.1	General maintenance.....	6
3.4	Install the grass catcher.....	4	5.2	Lubrication.....	6
3.5	Install the mulch plug.....	5	5.3	Replace the blade.....	6
3.6	Install the side discharge chute.....	5	5.4	Store the machine.....	7
3.7	Set the blade height.....	5	6	Troubleshooting.....	7
3.8	Install the battery pack.....	5	7	Technical data.....	7
3.9	Remove the battery pack.....	5			

1 DESCRIPTION

1.1 PURPOSE

This machine is used for domestic lawn mowing. The cutting blade must be approximately parallel to the ground. All four wheels must touch the ground while you mow.

1.2 OVERVIEW

Figure 1-11.

- | | |
|----|-------------------------|
| 1 | Bail lever |
| 2 | Start button |
| 3 | Upper handle |
| 4 | Lower handle |
| 5 | Rear discharge door |
| 6 | Height adjustment lever |
| 7 | Battery door |
| 8 | Grass catcher |
| 9 | Side discharge chute |
| 10 | Mulch plug |
| 11 | Handle knob |
| 12 | Knob |
| 13 | Bolt |
| 14 | Side discharge door |
| 15 | Battery pack |
| 16 | Battery release button |
| 17 | Safety key |
| 18 | Mounting screw |
| 19 | Spacer |
| 20 | Blade |

2 SAFETY

▲ WARNING

Make sure that you do/obey all safety instructions.

Refer to Safety Manual.

3 INSTALLATION

▲ WARNING

Do not change or make accessories that are not recommended by the manufacturer.

▲ WARNING

Do not put in the safety key or the battery pack until you assemble all the parts.

3.1 UNPACK THE MACHINE

▲ WARNING

Make sure that you correctly assemble the machine before use.

▲ WARNING

- If the parts have damage, do not use the machine.
- If you do not have all the parts, do not operate the machine.
- If the parts are damaged or missing, speak to the service center.

1. Open the package.
2. Read the documentation in the box.
3. Remove all the unassembled parts from the box.
4. Remove the machine from the box.
5. Discard the box and package in compliance with local regulations.

3.2 UNFOLD THE LOWER HANDLE

Figure 2.

1. Pull and turn the handle knobs 90°.
2. Unfold the lower handle.
3. Line up the handle knobs in one of the three positions on the brackets.
4. Turn the handle knobs 90° until they engage the holes in the brackets.

i NOTE

Make sure that the two handle knobs are in the same position.

▲ WARNING

Do not make damage to the cables when you fold or unfold the handle.

3.3 INSTALL THE UPPER HANDLE

Figure 3.

1. Align the holes in the upper handle and the lower handle.
2. Put the bolts through the holes.
3. Tighten the knobs onto the bolts.
4. Do the same operation on the other side.

3.4 INSTALL THE GRASS CATCHER

Figure 4.

1. Remove the mulch plug.
2. Remove the side discharge chute.
3. Open the rear discharge door and hold it.

4. Hold the the grass catcher by its handle and engage the hooks on the door rod.
5. Close the rear discharge door.

3.5 INSTALL THE MULCH PLUG

Figure 5.

1. Remove the grass catcher.
2. Open the rear discharge door and hold it.
3. Hold the mulch plug by its handle and fit it in the discharge chute.
4. Close the rear discharge door.

3.6 INSTALL THE SIDE DISCHARGE CHUTE

Figure 6.

▲ CAUTION

When you use the side discharge chute,

- do not install the grass catcher.
- keep the mulch plug installed.

1. Open the side discharge door and hold it.
2. Line up the recesses of the side discharge chute below the pivot.
3. Close the side discharge door.

3.7 SET THE BLADE HEIGHT

The machine can be set to different blade heights.

Figure 7.

1. Pull the height adjustment lever rearward to increase the blade height.
2. Pull the height adjustment lever forward to decrease the blade height.

3.8 INSTALL THE BATTERY PACK

Figure 8.

▲ WARNING

- If the battery pack or charger is damaged, replace the battery pack or the charger.
- Stop the machine and wait until the engine stops before you install or remove the battery pack.
- Read, know, and do the instructions in the battery and charger manual.

i NOTE

The machine has a battery storage compartment that helps store the battery.

1. Open the battery door.

2. Align the lift ribs on the battery pack with the grooves in the battery compartment.
3. Push the battery pack into the battery compartment until the battery pack locks into place.
4. When you hear a click, the battery pack is installed.
5. Close the battery door.

i NOTE

The engine starts only when you put in the safety key.

3.9 REMOVE THE BATTERY PACK

Figure 8.

1. Open the battery door.
2. Remove the safety key.
3. Push and hold the battery release button.
4. Remove the battery pack from the machine.

4 OPERATION

▲ WARNING

Wear eye protection during operation.

4.1 START THE MACHINE

Figure 9.

1. Put in the safety key.
2. Push and hold the start button.
3. While you hold the start button, pull the bail switch in the direction of the handle bar.
4. Release the start button to start the machine.

Soft-Start

This Li-ion machine has a “soft-start” feature.

When you start the machine, it goes to full speed after approximately 3 seconds.

i NOTE

If the machine does not start, remove the battery pack and examine the mower deck to make sure that:

- no grass catches on the blade.
- the blade can turn freely by hand.

4.2 STOP THE MACHINE

Figure 9.

1. Release the bail switch to stop the machine.

▲ WARNING

Wait until the blades fully stop before you start the machine again. Do not quickly turn the machine off and on.

▲ WARNING

Always remove the safety key and battery pack after you complete the work.

4.3 EMPTY THE GRASS CATCHER

Figure 10.

1. Stop the machine.
2. Remove the safety key.
3. Remove the battery pack.
4. Open the rear discharge door and hold it.
5. Hold the grass catcher by its handle and unhook it from the door rod.
6. Close the rear discharge door.
7. Empty the grass catcher.

4.4 OPERATE ON SLOPES**▲ WARNING**

Do not mow on the slopes with incline more than 15°. If you are not comfortable, do not mow on a slope.

- Do not go up and down on a slope, mow across the face of the slope. Be careful when you change the direction on a slope.
- Monitor the holes, ruts, rocks, and other hidden objects that can cause you to fall. Remove all obstacles such as rocks and tree limbs.
- Make sure that your footing is stable. If you are out of balance, release the bail switch immediately.
- Do not mow near drop-offs, ditches, or embankments.

4.5 OPERATION TIPS

- Do not tilt the machine when you start it.
- Do not put hands or feet near or below the turning parts.
- Keep the discharge chute clean.
- Do not cut wet grass.
- Higher blade height is necessary for new or thick grass.
- Clean the bottom of the mower deck after each use. Remove grass clippings, leaves, dirt, and other debris.

5 MAINTENANCE**▲ WARNING**

Remove the safety key and battery pack from the machine before maintenance.

▲ WARNING

Keep the engine and battery pack free from grass, leaves or too much grease.

▲ CAUTION

Use only approved replacement parts.

▲ CAUTION

Do not let brake fluids, gasoline, petroleum-based materials touch the plastic parts. Chemicals can cause damage to the plastic, and make the plastic unserviceable.

▲ CAUTION

Do not use strong solvents or detergents on the plastic housing or components.

5.1 GENERAL MAINTENANCE

- Before each use, examine the machine for damaged, missing, or loose parts such as screws, nuts, bolts and caps.
- Tighten correctly all the fasteners and caps.
- Clean the machine with a dry cloth. Do not use water.

5.2 LUBRICATION

Apply sufficient quantity of high grade lubricant to all bearings. No more bearing lubrication is necessary in usual operation conditions.

▲ WARNING

Do not lubricate the wheel components. Lubrication can cause damage to the wheel components during operation.

5.3 REPLACE THE BLADE

Figure 11.

▲ WARNING

Use only approved replacement blades.

▲ WARNING

Wear heavy gloves or wind cloth around the blade when you touch the blade.

1. Stop the machine.
2. Make sure that the blades fully stop.
3. Remove the safety key and battery pack.
4. Turn the machine to its side.
5. Use a piece of wood to prevent the movement of the blade.
6. Remove the mounting screw with a wrench or socket.
7. Remove the blade.
8. Install the new blade. Make sure that the arrows engage the holes in the blade.
9. Put in the mounting screw and tighten it.

5.4 STORE THE MACHINE

- Clean the machine before storage.
- Make sure the motor is not hot when you put the machine into storage.
- Make sure that the machine does not have loose or damaged parts. If it is necessary, do these steps/ instructions:
 - Replace the damaged parts.
 - Tighten the bolts.
 - Speak to a person of an approved service center.
- Store the machine in a dry area.
- Make sure that children cannot come near the machine.

You may lower the handle(s) before you put the machine into the storage.

1. Fully loosen the handle fasteners on the sides of the handle(s).
2. Fold away the handle(s).
3. Do not pinch or trap the cables.

6 TROUBLESHOOTING

Problem	Possible cause	Solution
The handle is not in position.	The bolts are not engaged correctly.	Adjust the height of the handle and make sure that the knobs and bolts are aligned correctly.
The machine does not start.	The battery capacity is low.	Charge the battery pack.
	The bail switch is defective.	Replace the bail switch.
	The battery key is not put in.	Put in the battery key.
The machine cuts grass unevenly.	The lawn is rough.	Examine the mowing area.
	The blade height is not set correctly.	Move the wheels to a higher position.
The machine does not mulch correctly.	Wet grass clippings attach to the deck.	Wait until the grass dries before mowing.
	The mulch plug is missing.	Install the mulch plug.
The machine is hard to push.	The grass is too tall, or the blade height is too low.	Increase the blade height.
	The grass catcher and the blade drags in thick grass.	Empty the grass clippings from the grass catcher.

Problem	Possible cause	Solution
There is a high vibration in the machine.	The blade is unbalanced and worn.	Replace the blade.
	The motor shaft is bent.	<ol style="list-style-type: none"> 1. Stop the motor. 2. Remove the safety key and battery pack. 3. Disconnect the power source. 4. Inspect for damage. 5. Repair the machine before you start it again.
The machine stops during mowing.	The blade height is too low.	Increase the blade height.
	The battery pack is out of power.	Charge the battery pack.
	The grass clippings attach to the deck or the blade.	Remove the battery pack and check the deck.
	Operation temperature of the machine is too high.	Cool the machine.

* If you cannot find the solution to these problems, go to the service center.

7 TECHNICAL DATA

Voltage	40 V
No load speed	2800 / min
Cut width	460 mm
Cut height	25 - 80 mm
Grass catcher capacity	55 L
Weight (without battery pack)	24,5 kg
Guaranteed sound power level	$L_{WA,d} = 96 \text{ dB(A)}$
Battery model	29727 and other BAF series
Charger model	29417 and other CAF series
Vibration	$< 2.5 \text{ m/s}^2$, $K = 1.5 \text{ m/s}^2$
IPX	IPX1

